

Machine Error.

If your Brother product is displaying an error code for example “Machine Error 10” or “Unable to Clean”, Then Your machine will need to go into a Brother Service agent for inspection.

[Please click here to find the closet service agent in your area.](#)

